


SPCC-P40001 SIGNATURE SERIES PISTOL TOOL

EXPLODED VIEW

PAGE 1 of 2



PARTS LIST — FOR REFERENCE ONLY

Index Number	Part Number	Description	Qty.	Index Number	Part Number	Description	Qty.	Index Number	Part Number	Description	Qty.
1	0-311027	C type Retainer Ring S62	1	2	0-231013	Thrust Needle Bearing NTA1625+2AS	1	22	33239-GWC090H-03	Washer 43 x 18 x 2t	2
2	33257-GWC400H-01	Reaction Bar	1	3	33249-GWC400H-05	Clutch Central Gear	1	23	33249-GWC090H-05	Central Gear	1
3	32049-GWC400H-01	Internal Gear Assembly	1	4	0-521046	Steel Ball 8	3	24	33251-GWC090H-06	Gear Plate	1
5	33249-GWC400H-02	Internal Gear	1	5	33251-GWC090H-05	Steel Ball Seat	1	25	0-511168	Pin (5 x 17L)	3
6	33254-GWC400H-01	Lock Nut	1	6	0-197001	Wave Spring 35 x 27 x 8.38	1	26	0-511107	Pin (1.5 x 10L)	39
7	33251-GWC400H-01	Gear Cage	1	7	0-231012	Thrust Needle Bearing NTB2035+2AS	1	27	33249-GWC090H-07	Planet Gear	3
8	33249-GWC400H-03	Planet Gear	4	8	33251-GWC090H-04	Clutch Gear	1	28	33251-GWC090H-03	Rotary Seat	1
9	0-511014	Pin (2 x 24.8L)	72	9	33249-GWC090H-06	Planet Gear	3	30	33254-GWC090H-01	Lock Nut	1
10	33255-016	Pin (12 x 40L)	4	10	0-511161	Pin (1.5 x 11.8L)	51	31	0-521010	Steel Ball 5	4
11	0-201040	Ball Bearing 6902ZZ (24 x 15 x 7T)	1	11	0-511170	Pin (7 x 22L)	3	32	1100-507	Spring	4
12	0-201109	Ball Bearing 6009ZZ (75 x 45 x 16T)	2	21	32029-GWC090-01	Clutch Assembly	1	33	33239-GWC090H-01	Washer 5 x 33 x 0.5t	1
13	33242-GWC400H-01	Bushing	2	1	0-101062	Cap Screw M6 x P1 x 12L	1	35	32051-GWC090H-01	Fixing Seat Assembly	1
14	0-198003	Spiral Retaining Ring DNH-78	2	2	33239-GWC090H-02	Washer 6 x 16 x 2.15	1	36	0-101071	Cap Screw M4 x P0.7 x 16L	4
15	33251-GWC400H-02	Gear Cage Seat	1	3	0-241003	Thrust Ball Bearing CRT8-16	1	37	0-101008	Cap Screw M4 x P0.7 x 25L	4
16	33249-GWC400H-04	Planet Gear	3	4	33229-GWC090H-01	Upper Clutch Unit	1	38	0-201058	Ball Bearing 6804ZZ (32 x 20 x 7T)	1
17	0-511011	Pin (2 x 15L)	54	5	0-521005	Steel Ball3	3	39	33252-GWC090H-01	Housing Cover	1
18	33255-017	Pin (10 x 27L)	3	6	33229-GWC090H-02	Lower Clutch Unit	1	40	0-101005	Cap Screw M4 x P0.7 x 6L	4
19	0-201011	Ball Bearing 688ZZ (16 x 8 x 5T)	1	7	33248-GWC090H-01	Spring	1	41	32098-GWC400H-01	Motor Housing Assembly	1
20	32049-GWC400-01	Clutch Gear Assembly	1	8	33254-GWC090H-03	Clutch Bolt	1	See Page 2			
1	0-321024	C type Retainer Ring R39	1	9	33251-GWC090H-08	Spring Seat	1	42	33239-GWC090H-04	Washer 31.9 x 25 x 2.5t	1
								43	1405-108	Bushing	2




10000 SE PINE
PORTLAND, OR 97216
503-254-6600
FAX 503-255-2615

When ordering spare parts, please specify
tool type, part number, and description.

REVISED 07/25

SPCC-P40001 SIGNATURE SERIES PISTOL TOOL

EXPLODED VIEW - PAGE 2



PARTS LIST — FOR REFERENCE ONLY

Index Number	Part Number	Description	Qty.	Index Number	Part Number	Description	Qty.	Index Number	Part Number	Description	Qty.
41	32098-GWC400H-01	Motor Housing Assembly	1	11	32050-PWAP-03	Gear Box Assembly	1	22	B09IWT#B1	F/R Valve 1 set x 2 pcs	1
1	0-151020	Self-Tapping Screw M4 x 16L	9	12	0-121005	Cap Screw M4 x P0.7 x 10L	4	23	D48IWT	Spring	1
2	33101-GWC090H-01	Upper Housing	1	13	0-511050	Pin (4 x 12.8L)	8	24	33110-NPA-02	Cover	1
3	32602-GWC090H-06	Lower Housing	1	14	32083-GWC400-01	Brushless Motor	1	25	B86IWT	Connector Wire	1
4	33249-GWC-01	Gear Ring	1	15	32076-GWC025-01	LCM Board Assembly	1	26	B86PW35	Connector Wire	1
5	33239-PWAP-04	Washer	1	16	33110-NPA-01	Cover	1	27	32076-GWC-01	PCB-Storage	1
6	33251-GWC090H-07	Gear Cage	1	17	0-152001	Self-Tapping Screw 3 x 14L	2	28	0-151018	Self-Tapping Screw 2.6 x 6L	4
7	33249-PWAP-09	Planet Gear 23T (Rohs)	3	18	32076-NPA-02	PC Board	1	29	33249-GWC090H-08	Central Gear	1
8	0-211003	Needle Bearing KT-477	3	19	B09PW#B1	Trigger Assembly	1				
9	0-511050	Pin (4 x 12.8L)	3	20	D48PW15	Spring	1				
10	33239-PWAP-02B	Washer 15.1 x 18.5 x 0.3t	1	21	C39PW15-3	Washer	1				



10000 SE PINE
PORTLAND, OR 97216
503-254-6600
FAX 503-255-2615

When ordering spare parts, please specify
tool type, part number, and description.