


UX-450S & UX-450SD OIL-PULSE TOOLS

EXPLODED VIEW



PARTS LIST — FOR REFERENCE ONLY

Index Number	Part Number	Description	Qty.	Index Number	Part Number	Description	Qty.	Index Number	Part Number	Description	Qty.
1	177-025-3	Casing	1	25	174-907-8	Relief Valve Spindle	1 ●	53	990-152-0	O-Ring	1
2	480-100-9	Valve	1	26	178-742-0	Oil Plug	1 ●	53-1	944-213-0	Supporter Ring (12 x 16 x 1)	1
3	196-107-7	Valve Lever	1	27	178-327-0	Front Anvil Spacer	1 ●	COMPONENTS FOR UX-450SD (1/4" HEXAGON FEMALE HEAD)			
4	177-210-3	Reverse Valve	1	28	010-790-1	Suspender	1 ●	54	177-350-7	Driver Anvil	1
5	180-212-2	Reverse Lever	1	29	944-002-0	Supporting Ring (2.6 x 4.5 x 1)	2 ●	55	011-351-1	Bit Sleeve	1
6	408-782-1	Silencer	1	30	966-099-0	Allen Head Plug (NPT 1/16) (GDL TYPE)	1 ●	56	011-352-1	Bit Spacer	1
7	471-835-5	Filter (F100)	2	32	970-130-0	Pin (H) (2.45 x 4.5)	2 ●	57	976-327-0	Spring (13.5 x 11)	1
8	480-091-8	Air Inlet Bushing	1	33	970-135-0	Pin (H) (2.45 x 11)	2 ●	58	978-117-8	Snap Ring (11.7 x 1.0)	1
9	177-291-3	Rear Plate Spacer	1	34	970-217-0	Pin (H) (3 x 17)	1 ●	59	981-002-0	Ball (1/8)	1
10	177-285-3	Rear Plate	1	35	973-022-0	Roll Pin (2 x 22)	1 ●	ACCESSORIES			
11	177-286-3	Cylinder	1	36	973-005-0	Roll Pin (2 x 5)	2 ●	60	939-091-0	Allen Wrench (1.5)	1
12	177-287-3	Rotor	1	37	973-006-0	Roll Pin (2 x 6)	1 ●	61	939-105-0	Allen Wrench (4)	1
13	182-288-2	Blade	6	38	973-018-0	Roll Pin (2 x 18)	1 ●	Assembly Code Numbers			
14	177-289-3	Front Plate	1	39	973-122-0	Roll Pin (3 x 22)	1 ●	891-328-1	Liner Casing Assembly (OP-0) for UX-450S		
15	177-036-5	Front Casing Connector	1	41	976-791-0	Spring (3.3 x 21) (0.4) WPC	2 ●	177-911-5	Liner Casing Assembly (0) for UX-450S		
16	177-439-5	Front Casing	1	42	977-150-0	Cone Spring (6.8 x 8.5 x 8)	1 ●	177-911-6	Liner Casing Assembly for UX-450SD		
17	190-328-6	Anvil Bushing	1	43	978-282-0	Snap Ring (28 x 1.0)	1 ●	177-984-3	Handle Assembly		
18	196-901-4	Rear Liner Plate	1	44	981-206-0	Ball (1/4)	1 ●				
19	177-902-5	Liner	1	45	982-401-0	Ball Bearing (EE-2)	1 ●				
20	891-307-1	Anvil Assembly (OP-P)	1	46	982-402-0	Ball Bearing (EE-3)	1 ●				
20-1	891-300-1	Socket Retainer Assembly	1 ●	47	990-321-0	O-Ring (ARPS68-104)	1 ●				
20-2	177-319-5	Anvil (0)	1 ●	48	990-320-0	O-Ring (ARPS68-003)	2 ●				
21	177-440-5	Driving Blade	2	49	990-329-0	O-Ring (JW1530-19)	1 ●				
22	178-904-8	Front Liner Plate	1	51	990-907-0	O-Ring (SNS9)	1 ●				
23	177-905-6	Liner Casing	1	52	990-909-0	O-Ring (SNS11.2)	2 ●				
24	190-906-6	Liner Casing Setter	1								

AIMCO also offers a complete line of standard & special adapters, bits, sockets, and extensions



10000 SE PINE
PORTLAND, OR 97216
503-254-6600
FAX 503-255-2615

When ordering spare parts, please specify tool type, part number, and description.

FOOTNOTES

● = Components for 891-307-1 Anvil Assembly