


# 5001 DIE GRINDER

## EXPLODED VIEW



## PARTS LIST — FOR REFERENCE ONLY

Index Number	Part Number	Description	Qty.	Index Number	Part Number	Description	Qty.
1	50101	Rotor Case	1	17	30117	Lock Pin	2
2	50102	Spring Pin	1	18	30118	Cylinder	1
3	50103	Air Inlet	1	19	50119C	Bottom Plate	1
4	50104	Lever	1	20	030120	Ball Bearing	1
5	30105	Throttle Valve	1	21	40145	Steel Ball	1
7	30107	O-Ring	1	22	50122	Collet Washer	1
8	30108	Throttle Spring	1	23	50123	Collar	1
9	50109	Handle	1	24	51224	Collet Body	1
10	30110	Plug	1	25	51225	Collet Nut	1
11	30111	End Cap Plate	1	26	50126	Safety Lever	1
12	50112	Rotor Bushing	1	27	50127	Spring Pin	1
13	030113	Ball Bearing	1	28	50128	Safety Lever Spring	1
14	30114	Top Plate	1	29	30109	O-Ring	1
15	50115C	Rotor	1	30	51227	Angle Double Ended Spanner	1
16	30116	Vane	4	31	51228	Double Ended Spanner	1



10000 SE Pine Street  
Portland, OR 97216  
503-254-6600  
FAX 503-255-2615

When ordering spare parts, please specify  
tool type, part number and description.

### FOOTNOTES