


# 7650 ANGLE DRILL - REVERSIBLE

## EXPLODED VIEW



## PARTS LIST — FOR REFERENCE ONLY

Index Number	Part Number	Description	Qty.	Index Number	Part Number	Description	Qty.	Index Number	Part Number	Description	Qty.
1	RC4650C-01	Motor Housing incl. part 18 + 21	1	25	RC4650C-25RK	Rotor Ball Bearing	1	46	RC4650C-46RK	Ball Bearing	1
3	RC4650C-03	Air Inlet incl. part 2	1	27	RC4650C-27TK	Motor Gasket	1	47	RC4650C-47RK	Retainer Ring	1
4	RC4650C-04	Deflector	1	28	RC4650C-28	Rear End Plate	1	49	RC4650C-49RK	Key	1
6	RC4650C-06	Deflector Stop Ring	1	29	RC4650C-29	Cylinder	1	51	RC4650C-51	Ball Bearing Cap	1
7	RC4650C-07	Housing Cap	1	30	RC4650C-30	Rotor	1	52	RC4650C-52	Retainer Ring	1
8	RC4650C-08	Screw	2	31	RC4650C-31TK	Rotor Blade	5	55	RC4650C-55	Chuck Screw	1
9	RC4650C-09	Throttle Lever	1	32	RC4650C-32	Motor Pin	1	57	RC4650C-57RK	Wave Washer	1
10	RC4650C-10	Spring Pin	1	33	RC4650C-33	Front End Plate	1	58	RC4650C-58	Key/Accessory: 844005	1
11	RC4650C-11TK	Housing Gasket	1	34	RC4650C-34TK	Rotor Ball Bearing	1	59	RC4650C-59	Drill Chuck/Acc.:844004	1
12	RC4650C-12	Valve Screw	1	35	RC4650C-35	Lock Ring	1	60	RC4650C-60RK	Spindle	1
13	RC4650C-13TK	Valve Screw O-Ring	1	36	RC4650C-36	Internal Gear	1	62	RC4650C-61TK	Ball Bearing	1
14	RC4650C-14RK	Throttle Valve Spring	1	37	RC4650C-37RK	Planet Gear	3				
15	RC4650C-15TK	Throttle Valve	1	39	RC4650C-39	Planet Cage with Pin	1				
16	RC4650C-16TK	Throttle Valve O-Ring	1	40	RC4650C-40	Ball Bearing Case	1				
20	RC4650C-20TK	Reverse Retainer	1	41	RC4650C-41	Spindle Shaft	1				
22	RC4650C-22	Spring Pin	1	42	RC4650C-42TK	Ball Bearing	1				
23	RC4650C-23	Reverse Valve	1	43	RC4650C-43RK	Pinion	1				
24	RC4650C-24TK	Reverse Valve Spring	1	44	RC4650C-44RK	Gear	1				
				45	RC4650C-45RK	Angle Housing incl. part 53 +	1				

### FOOTNOTES



When ordering spare parts, please specify tool type, part number and description.

10000 SE PINE ST., PORTLAND, OR 97216  
503-254-6600 FAX 503-254-7215