


BRH-1USD & BRH-5USD SUPER VIBRATION-PROOF RIVETING HAMMER

EXPLODED VIEW



PARTS LIST — FOR REFERENCE ONLY

Index Number	Part Number	Description	Qty.	Index Number	Part Number	Description	Qty.	Index Number	Part Number	Description	Qty.
2	180-091-6	Air Inlet Bushing	1	54	990-861-0	O-Ring (P50A) (Vibration-proof)	1	ACCESSORIES			
3	201-108-1	Valve Plug	1	55	990-918-0	O-Ring (SNS-20)	1	Accessories for BRH-1USD(R)			
4	235-885-0	Silencer Assembly	1	56	990-934-0	O-Ring (SNS-44)	1	1	174-790-0	Suspension Bail	1
5	508-914-4	Self-Locking Lever Assembly	1	57	990-989-0	O-Ring (SNS-60)	1	10	705-810-1	Retainer Spring (Small)	1
14	708-682-8	Buffer Bushing	1	COMPONENTS FOR BRH-1USD(R) & (H)				34	876-179-1	Retainer Spring (Flat) (L=32)	1
15	708-834-8	Vibration-Proof Rubber (1 less for BRH-1UD)	3	6	705-195-1	Main Valve	1	35	920-021-0	Round Head Rivet Set (3.0)	1
21	709-740-2	Pipe	1	7	705-196-1	Valve Box	1	37	920-800-0	Flat Head Rivet Set (Large)	1
22	709-840-2	Handle Cover	1	8	705-197-1	Valve Box Cover	1	38	940-116-0	Air Hose Nipple (NPT 1/4 x 3/8)	1
27	710-782-8	Exhaust Deflector	1	9	705-546-1	Piston	1	Accessories for BRH-1USD(H)			
30	711-767-7	Casing Cover	1	11	708-286-8	Cylinder	1	1	174-790-0	Suspension Bail	1
31	711-805-7	O-Ring Cover	1	COMPONENTS FOR BRH-5USD(R) & (H)				10	705-810-1	Retainer Spring (Small)	1
32	850-157-1	Valve Bushing	1	19	709-286-4	Cylinder	1	34	876-179-1	Retainer Spring (Flat) (L=32)	1
33	850-158-1	Valve	1	23	710-195-1	Main Valve	1	38	940-116-0	Air Hose Nipple (NPT 1/4 x 3/8)	1
39	969-449-0	Pin (G) (3 x 6)	2	24	710-196-1	Valve Box	1	Accessories for BRH-5USD(R)			
40	970-228-0	Pin (H) (3 x 28)	1	25	710-197-1	Valve Box Cover	1	1	174-790-0	Suspension Bail	1
41	973-124-0	Roll Pin (3 x 24)	1	26	710-546-2	Piston	1	28	710-812-1	Retainer Spring (Large)	1
42	976-151-0	Spring (7 x 16) (0.7)	1	COMPONENTS FOR BRH-1USD(R) & BRH-5USD(R)				34	876-179-1	Retainer Spring (Flat) (L=32)	1
43	979-015-0	Inner Snap Ring (22)	1	12	708-567-8	Bushing (R)	1	36	920-040-0	Round Head Rivet Set (6.0)	1
44	979-127-0	Outer Snap Ring (30)	1	16	709-011-2	Handle	1	37	920-800-0	Flat Head Rivet Set (Large)	1
45	980-005-0	Round Head Notch (2.5)	1	29	711-025-7	Casing	1	38	940-116-0	Air Hose Nipple (NPT 1/4 x 3/8)	1
46	980-006-0	Round Head Notch (3)	1	COMPONENTS FOR BRH-1USD(H) AND BRH-5USD(H)				1	174-790-0	Suspension Bail	1
47	980-010-0	Flat Head Notch (3)	1	13	708-567-9	Bushing (H)	1	28	710-812-1	Retainer Spring (Large)	1
48	981-206-0	Ball (1/4)	1	17	709-011-3	Handle	2	34	876-179-1	Retainer Spring (Flat) (L=32)	1
49	990-008-0	O-Ring (P10)	2	18	709-025-3	Casing	1	38	940-116-0	Air Hose Nipple (NPT 1/4 x 3/8)	1
50	990-027-0	O-Ring (P28)	1	20	709-562-3	Stopper	2	Accessories for BRH-5USD(H)			
51	990-045-0	O-Ring (P48A)	1	FOOTNOTES				1	174-790-0	Suspension Bail	1
52	990-047-0	O-Ring (P50A)	1	When ordering spare parts, please specify tool type, part number, and description.				28	710-812-1	Retainer Spring (Large)	1
53	990-860-0	O-Ring (P48A) (Vibration-proof)	1	REVISED 09/20				34	876-179-1	Retainer Spring (Flat) (L=32)	1



**10000 SE PINE
PORTLAND, OR 97216
503-254-6600
FAX 503-255-2615**

When ordering spare parts, please specify
tool type, part number, and description.