


SBH-0 & SBH-1AR(H) BABY RIVETING HAMMER

EXPLODED VIEW



Handle Assembly
Part #700-002-1
Components marked with ●

Handle Assembly
Part #701-002-1
Components marked with ■

PARTS LIST — FOR REFERENCE ONLY

Index Number	Part Number	Description	Qty.	Index Number	Part Number	Description	Qty.	Index Number	Part Number	Description	Qty.
PARTS FOR SBH-0				PARTS FOR SBH-1AR(H)				ACCESSORIES FOR SBH-1AR(H)			
1	700-011-1	Handle	1 ●	19	942-101-0	Connecting Screw (1/8 x 1/8)	1	14	786-567-1	Bushing (Hex)	1
2	700-107--1	Valve Lever	1 ●	20	700-810-1	Retainer Spring (small)	1	15	701-782-2	Exhaust Deflector	1
3	601-108-1	Valve Plug	1 ●	21	920-004-0	Round Head Rivet Set (2.0)	1	16	701-565-1	Lock Sleeve Key	1
4	700-285-1	Rear Plate	1	22	920-810-0	Flat Head Rivet Set (2.3)	1	17	701-764-1	Notch Pin (3 x 17)	2
5	700-286-1	Cylinder	1	PARTS FOR SBH-1AR(H)				18	970-240-0	Pin (H) (3 x 24)	1 ■
6	700-203-1	O-Ring Spacer	1	1	701-022-1	Handle	1 ■	19	973-124-0	Roll Pin (3 x 24)	1 ■
7	700-546-1	Piston	1	2	010-102-1	Valve Bushing	1 ■	20	981-207-0	Ball (9/32)	1 ■
8	700-782-1	Exhaust Deflector	1	3	701-106-1	Valve Rod Cap	1 ■	21	976-151-0	Spring (7 x 16)	1 ■
9	970-215-0	Pin (A) (3 x 14.5)	1 ●	4	201-108-1	Valve Plug	1 ■	ACCESSORIES FOR SBH-1AR(H)			
10	973-118-0	Roll Pin (3 x 18)	1 ●	5	500-107-1	Valve Lever	1 ■	22	010-790-1	Suspension Ring	1
11	976-066-0	Spring (4.6 x 9)	1 ●	6	185-091-7	Air Inlet Bushing	1 ■	23	932-110-0	Air Regulator (U 1/4)	1
12	981-205-0	Steel Ball (7/32)	1 ●	7	701-198-1	Rear Valve Seat	1	25	705-810-1	Retainer Spring (small)	1
13	990-017-0	O-Ring (P18)	1	8	701-199-1	Medium Valve Seat	1	26	708-813-8	Retainer Spring (flat)	1
14	990-904-0	O-Ring (SNS-6)	1 ●	9	701-200-1	Front Valve Seat	1	27	920-020-0	Round Head Rivet Set (2.6)	1
ACCESSORIES FOR SBH-0				10	701-195-1	Main Valve	1	28	920-801-0	Flat Head Rivet Set (3.0)	1
15	401-790-1	Suspension Ring	1	11	701-288-1	Cylinder	1				
16	932-100-0	Air Regulator (U 1/8")	1	12	701-546-1	Piston	1				
				13	705-567-1	Bushing (Round)	1				

FOOTNOTES

- = Component in SBH-0 Handle Assembly #700-002-1
- = Component in SBH-1A Handle Assembly #701-002-1



10000 SE PINE
PORTLAND, OR 97216
503-254-6600
FAX 503-255-2615

When ordering spare parts, please specify tool type, part number, and description.