




ULT Series Repair Limits Manual




Contents

<u>ULT Series</u>	<u>Page Number</u>
1. Rear Plate	3
2. Cylinder	5
3. Rotor	7
4. Blade	9
5. Front Plate	11
6. Anvil	13
7. Driving Blade	16
8. Rear Liner Plate	18
9. Liner	20
10. Front Liner Plate	22


Repair Limits - ULT Series

REPAIR LIMITS		REAR PLATE (ULT)		1/2	
					
<p>Note Make sure that any deformation is not observed.</p>					
CODE NO.	MOTHER MODEL	STANDARD DIMENSION		REPAIR LIMIT	MODEL
144-285-0	ULT30D	A	31	30.97	ULT30D, ULT30D(V)
		B	-----	0.03	ULT30D(TM)
128-285-5	ULT30SD	A	31	30.97	ULT30SD, ULT30SD(V)
		B	-----	0.03	ULT30SD(TM)
128-285-6	ULT40S	A	31	30.97	ULT40S, ULT40SD, ULT40S(TM)
		B	-----	0.03	ULT40SD(TM)
128-285-8	ULT50S	A	33	32.97	ULT50S, ULT50SD, ULT50SL ULT50SDL, ULT50S(TM)
		B	-----	0.03	ULT50SD(TM), ULT50SL(TM) ULT50SDL(TM), ULT50C, ULT50CL ULT50C(TM), ULT50CL(TM)
145-285-6	ULT60	A	33	32.97	ULT40, ULT40D, ULT40D(V) ULT40D(T), ULT40(TM) ULT40D(TM), ULT40T2(TM) ULT40DT2(TM), ULT50, ULT50D ULT50L, ULT50DL, ULT50D(V) ULT50DL(V), ULT50D(T) ULT50DL(T), ULT50(TM) ULT50D(TM), ULT50L(TM)
		B	-----	0.03	ULT50DL(TM), ULT50T2(TM) ULT50DT2(TM), ULT60, ULT60D ULT60L, ULT60DL, ULT60D(V) ULT60DL(V), ULT60D(T) ULT60DL(T), ULT60(TM) ULT60D(TM), ULT60L(TM) ULT60DL(TM), ULT60T2(TM) ULT60DT2(TM)
129-285-2	ULT60S	A	33	32.97	ULT51SDL, ULT51SDL(TM), ULT60S, ULT60SD, ULT60SL ULT60SDL, ULT60S(TM) ULT60SD(TM), ULT60SL(TM) ULT60SDL(TM), ULT60C, ULT60CL
		B	-----	0.03	ULT60C(TM), ULT60CL(TM) ULT70S, ULT70SL, ULT70S(TM) ULT70SL(TM), ULT70C, ULT70CL ULT70C(TM), ULT70CL(TM) ULT70CH, ULT70CHL ULT70CH(TM), ULT70CHL(TM)


Repair Limits - ULT Series

REPAIR LIMITS		CYLINDER (ULT)		1/2	
					
<p>Note 1: Make sure that neither deformation nor damage is observed.</p> <p>Note 2: Make sure that the inner surface is flat and smooth, not wavelike.</p>					
CODE NO.	MOTHER MODEL	STANDARD DIMENSION	REPAIR LIMIT	MODEL	
144-286-0	ULT30D	B	22	22.051	ULT30D, ULT30D(V)
		C	32	31.995	ULT30D(TM)
128-286-5	ULT30SD	B	22	22.051	ULT30SD, ULT30SD(V)
		C	32	31.995	ULT30SD(TM)
147-286-0	ULT40D	B	23.5	23.551	ULT40, ULT40D, ULT40D(V) ULT40D(T), ULT40(TM)
		C	32	31.995	ULT40D(TM), ULT40T2(TM) ULT40DT2(TM)
145-286-0	ULT50	B	23.5	23.551	ULT50, ULT50D, ULT50L ULT50DL, ULT50D(V) ULT50DL(V), ULT50D(T) ULT50DL(T), ULT50(TM)
		C	32	31.995	ULT50D(TM), ULT50L(TM) ULT50DL(TM), ULT50T2(TM) ULT50DT2(TM)
128-286-8	ULT50S	B	23.5	23.551	ULT40S, ULT40SD, ULT40S(TM) ULT40SD(TM), ULT50S ULT50SD, ULT50SL, ULT50SDL ULT50S(TM), ULT50SD(TM)
		C	32	31.995	ULT50SL(TM), ULT50SDL(TM) ULT50C, ULT50CL, ULT50C(TM) ULT50CL(TM)
145-286-6	ULT60	B	23.5	23.551	ULT60, ULT60D, ULT60L ULT60DL, ULT60D(V) ULT60DL(V), ULT60D(T) ULT60DL(T), ULT60(TM)
		C	38	37.995	ULT60D(TM), ULT60L(TM) ULT60DL(TM), ULT60T2(TM) ULT60DT2(TM)
129-286-2	ULT60S	B	23.5	23.551	ULT51SDL, ULT51SDL(TM) ULT60S, ULT60SD, ULT60SL ULT60SDL, ULT60S(TM)
		C	38	37.995	ULT60SD(TM), ULT60SL(TM) ULT60SDL(TM), ULT60C ULT60CL, ULT60C(TM) ULT60CL(TM)


Repair Limits - ULT Series

REPAIR LIMITS		ROTOR (ULT)			1/2
					
Note Make sure that any deformation is not observed					
CODE NO.	MOTHER MODEL	STANDARD DIMENSION		REPAIR LIMIT	MODEL
144-287-0	ULT30D	A	32	31.925	ULT30D, ULT30D(V) ULT30D(TM), ULT30SD ULT30SD(V), ULT30SD(TM)
		B	22	21.918	
145-287-0	ULT50	A	32	31.925	ULT40, ULT40D, ULT40D(V) ULT40D(T), ULT40(TM) ULT40D(TM), ULT40T2(TM) ULT40DT2(TM), ULT40S ULT40SD, ULT40S(TM) ULT40SD(TM), ULT50, ULT50D ULT50L, ULT50DL, ULT50D(V) ULT50DL(V), ULT50D(T) ULT50DL(T), ULT50(TM) ULT50D(TM), ULT50L(TM) ULT50DL(TM), ULT50T2(TM) ULT50DT2(TM), ULT50S ULT50SD, ULT50SL, ULT50SDL ULT50S(TM), ULT50SD(TM) ULT50SL(TM), ULT50SDL(TM) ULT50C, ULT50CL, ULT50C(TM) ULT50CL(TM)
		B	23.5	23.418	
145-287-6	ULT60	A	38	37.925	ULT51SDL, ULT51SDL(TM) ULT60, ULT60D, ULT60L ULT60DL, ULT60D(V) ULT60DL(V), ULT60D(T) ULT60DL(T), ULT60(TM) ULT60D(TM), ULT60L(TM) ULT60DL(TM), ULT60T2(TM) ULT60DT2(TM), ULT60S ULT60SD, ULT60SL, ULT60SDL ULT60S(TM), ULT60SD(TM) ULT60SL(TM), ULT60SDL(TM) ULT60C, ULT60CL, ULT60C(TM) ULT60CL(TM)
		B	23.5	23.418	
147-287-6	ULT70	A	45	44.925	ULT70, ULT70L, ULT70(TM) ULT70L(TM), ULT70T2(TM)
		B	24.5	24.418	


Repair Limits - ULT Series

REPAIR LIMITS		BLADE (ULT)		1/2	
					
Note Make sure that any deformation is not observed.					
CODE NO.	MOTHER MODEL	STANDARD DIMENSION	REPAIR LIMIT	MODEL	
144-288-0	ULT30D	A	32	31.86	ULT30D, ULT30D(V) ULT30D(TM), ULT30SD ULT30SD(V), ULT30SD(TM)
		B	1.65	1.61	
		C	7.4	7.1	
		D	-----	0.1	
145-288-0	ULT50	A	32	31.86	ULT40, ULT40D, ULT40D(V) ULT40D(T), ULT40(TM) ULT40D(TM), ULT40T2(TM) ULT40DT2(TM), ULT40S ULT40SD, ULT40S(TM) ULT40SD(TM), ULT50, ULT50D ULT50L, ULT50DL, ULT50D(V) ULT50DL(V), ULT50D(T) ULT50DL(T), ULT50(TM) ULT50D(TM), ULT50L(TM) ULT50DL(TM), ULT50T2(TM) ULT50DT2(TM), ULT50S ULT50SD, ULT50SL, ULT50SDL ULT50S(TM), ULT50SD(TM) ULT50SL(TM), ULT50SDL(TM) ULT50C, ULT50CL, ULT50C(TM) ULT50CL(TM)
		B	1.65	1.61	
		C	8.3	7.8	
		D	-----	0.1	
147-288-2	ALPHA-L61	A	38	37.86	ULT51SDL, ULT51SDL(TM) ULT60, ULT60D, ULT60L ULT60DL, ULT60D(V) ULT60DL(V), ULT60D(T) ULT60DL(T), ULT60(TM) ULT60D(TM), ULT60L(TM) ULT60DL(TM), ULT60T2(TM) ULT60DT2(TM), ULT60S ULT60SD, ULT60SL, ULT60SDL ULT60S(TM), ULT60SD(TM) ULT60SL(TM), ULT60SDL(TM), ULT60C, ULT60CL ULT60C(TM), ULT60CL(TM)
		B	1.65	1.61	
		C	8.3	7.8	
		D	-----	0.1	
147-288-6	ULT70	A	45	44.84	ULT70, ULT70L, ULT70(TM) ULT70L(TM), ULT70T2(TM)
		B	1.65	1.61	
		C	8.3	7.8	
		D	-----	0.1	


Repair Limits - ULT Series

REPAIR LIMITS		BLADE (ULT)		2/2	
					
Note Make sure that any deformation is not observed.					
CODE NO.	MOTHER MODEL	STANDARD DIMENSION	REPAIR LIMIT	MODEL	
129-288-6	ULT70S	A	48	44.84	ULT70S, ULT70SL, ULT70S(TM)
		B	1.65	1.61	ULT70SL(TM), ULT70C
		C	8.3	7.8	ULT70CL, ULT70C(TM)
		D	-----	0.1	ULT70CL(TM), ULT70CH ULT70CHL, ULT70CH(TM) ULT70CHL(TM)
147-288-8	ULT90	A	45	44.84	ULT90, ULT90L, ULT90(TM) ULT90L(TM), ULT90T2(TM)
		B	1.85	1.81	
		C	10.8	10.3	
		D	-----	0.1	
148-288-2	ULT100	A	45	44.84	ULT100, ULT100L, ULT100(TM) ULT100L(TM), ULT100T2(TM)
		B	1.85	1.81	
		C	11.8	11.3	
		D	-----	0.1	
130-288-2	ULT130	A	53	52.84	ULT130, ULT130L, ULT130(TM) ULT130L(TM), ULT130T2(TM) ULT150, ULT150L, ULT150(TM) ULT150L(TM)
		B	2.35	2.31	
		C	12.8	12.3	
		D	-----	0.1	
128-288-2	ULT180	A	58	57.84	ULT180, ULT180L, ULT180(TM) ULT180L(TM)
		B	2.85	2.81	
		C	15.6	15.1	
		D	-----	0.1	


Repair Limits - ULT Series

REPAIR LIMITS		FRONT PLATE (ULT)		1/2	
					
Note Make sure that any deformation is not observed					
CODE NO.	MOTHER MODEL	STANDARD DIMENSION		REPAIR LIMIT	MODEL
144-289-0	ULT30D	A	31	30.97	ULT30D, ULT30D(V) ULT30D(TM)
		B	-----	0.03	
128-289-5	ULT30SD	A	31	30.97	ULT30SD, ULT30SD(V) ULT30SD(TM)
		B	-----	0.03	
128-289-8	ULT50S	A	33	32.97	ULT40S, ULT40SD, ULT40S(TM) ULT40SD(TM), ULT50S, ULT50SD ULT50SL, ULT50SDL, ULT50S(TM) ULT50SD(TM), ULT50SL(TM) ULT50SDL(TM), ULT50C, ULT50CL ULT50C(TM), ULT50CL(TM) ULT51SDL, ULT51SDL(TM) ULT60S, ULT60SD, ULT60SL ULT60SDL, ULT60S(TM) ULT60SD(TM), ULT60SL(TM) ULT60SDL(TM), ULT60C, ULT60CL ULT60C(TM), ULT60CL(TM) ULT70S, ULT70SL, ULT70S(TM) ULT70SL(TM), ULT70C, ULT70CL ULT70C(TM), ULT70CL(TM) ULT70CH, ULT70CHL ULT70CH(TM), ULT70CHL(TM)
		B	-----	0.03	
145-289-6	ULT60	A	33	32.97	ULT40, ULT40D, ULT40D(V) ULT40D(T), ULT40(TM) ULT40D(TM) , ULT40T2(TM) ULT40DT2(TM), ULT50, ULT50D ULT50L, ULT50DL, ULT50D(V) ULT50DL(V), ULT50D(T) ULT50DL(T), ULT50(TM) ULT50D(TM), ULT50L(TM) ULT50DL(TM), ULT50T2(TM) ULT50DT2(TM), ULT60, ULT60D ULT60L, ULT60DL, ULT60D(V) ULT60DL(V), ULT60D(T) ULT60DL(T), ULT60(TM) ULT60D(TM), ULT60L(TM) ULT60DL(TM), ULT60T2(TM) ULT60DT2(TM)
		B	-----	0.03	


Repair Limits - ULT Series

REPAIR LIMITS		ANVIL (ULT)			1/3
					
<p>Note 1: Make sure that neither deformation nor damage is observed.</p> <p>Note 2: Make sure that no damage on contact surface is observed.</p>					
CODE NO.	MOTHER MODEL	STANDARD DIMENSION		REPAIR LIMIT	MODEL
144-350-0	ULT30D	A	21	20.95	ULT30D, ULT30D(TM), ULT30SD ULT30SD(TM)
		B	16	15.935	
		C	12	11.973	
		D	10	9.96	
850-975-1	ULT30D(V)	A	21	20.95	ULT30D(V), ULT30SD(V)
		B	16	15.935	
		C	12	11.973	
		D	10	9.96	
145-350-2	ULT50D	A	21	20.95	ULT40D, ULT40D(TM) ULT40DT2(TM), ULT40SD ULT40SD(TM), ULT50D ULT50DL, ULT50D(TM) ULT50DL(TM), ULT50DT2(TM) ULT50SD, ULT50SDL ULT50SD(TM), ULT50SDL(TM) ULT51SDL, ULT51SDL(TM)
		B	18	17.935	
		C	15	14.973	
		D	12	11.96	
850-971-0	ULT50D(V)	A	21	20.95	ULT40D(T), ULT50D(T) ULT50DL(T)
		B	18	17.935	
		C	15	14.973	
		D	12	11.96	
850-971-0	ULT50D(V)	A	21	20.95	ULT40D(V), ULT50D(V) ULT50DL(V)
		B	18	17.935	
		C	15	14.973	
		D	12	11.96	
145-350-7	ULT60D	A	26	25.95	ULT60D, ULT60DL, ULT60D(TM) ULT60DL(TM), ULT60DT2(TM) ULT60SD, ULT60SDL ULT60SD(TM), ULT60SDL(TM)
		B	18	17.935	
		C	15	14.973	
		D	12	11.96	
850-970-1	ULT60D(V)	A	26	25.95	ULT60D(T), ULT60DL(T)
		B	18	17.935	
		C	15	14.973	
		D	12	11.96	
850-970-1	ULT60D(V)	A	26	25.95	ULT60D(V), ULT60DL(V)
		B	18	17.935	
		C	15	14.973	
		D	12	11.96	


Repair Limits - ULT Series

REPAIR LIMITS		ANVIL (ULT)			2/3
					
<p>Note 1: Make sure that neither deformation nor damage is observed.</p> <p>Note 2: Make sure that no damage on contact surface is observed.</p>					
CODE NO.	MOTHER MODEL	STANDARD DIMENSION	REPAIR LIMIT	MODEL	
145-319-0	ULT50	A	21	20.95	ULT40, ULT40(TM) ULT40T2(TM), ULT40S ULT40S(TM), ULT50, ULT50L ULT50(TM), ULT50L(TM) ULT50T2(TM), ULT50S ULT50SL, ULT50S(TM) ULT50SL(TM)
		B	18	17.935	
		C	15	14.973	
		D	12	11.96	
145-319-6	ULT60	A	26	25.95	ULT60, ULT60L, ULT60(TM) ULT60L(TM), ULT60T2(TM) ULT60S, ULT60SL ULT60S(TM), ULT60SL(TM) ULT60C, ULT60CL ULT60C(TM), ULT60CL(TM)
		B	18	17.935	
		C	15	14.973	
		D	12	11.96	
147-319-6	ULT70	A	28	27.95	ULT70, ULT70L, ULT70(TM) ULT70L(TM), ULT70T2(TM) ULT70S, ULT70SL, ULT70S(TM) ULT70SL(TM), ULT70C ULT70CL, ULT70C(TM) ULT70CL(TM), ULT70CH ULT70CHL, ULT70CH(TM) ULT70CHL(TM)
		B	20	19.94	
		C	16	15.973	
		D	12	11.96	
147-319-8	ULT90	A	30	29.95	ULT90, ULT90L, ULT90(TM) ULT90L(TM), ULT90T2(TM)
		B	23	22.94	
		C	19.9	19.87	
		D	14	13.95	
148-319-2	ULT100	A	35	34.95	ULT100, ULT100L, ULT100(TM) ULT100L(TM), ULT100T2(TM)
		B	26	25.94	
		C	19.9	19.87	
		D	16	15.95	
130-319-2	ULT130	A	40	39.95	ULT130, ULT130L, ULT130(TM) ULT130L(TM), ULT130T2(TM)
		B	27	26.94	
		C	19.9	19.87	
		D	16	15.95	
130-319-4	ULT150	A	40	39.95	ULT150, ULT150L, ULT150(TM) ULT150L(TM)
		B	32	31.94	
		C	25.2	25.15	
		D	17	16.96	


Repair Limits - ULT Series

REPAIR LIMITS		DRIVING BLADE (ULT)			1/2
					
<p>Note 1: Make sure that neither deformation nor damage is observed.</p> <p>Note 2: Make sure that no damage on contact surface is observed.</p>					
CODE NO.	MOTHER MODEL	STANDARD DIMENSION		REPAIR LIMIT	MODEL
144-440-0 (145-974-0 for Roller)	ULT30D	A	21	20.95	ULT30D, ULT30D(V) ULT30D(TM), ULT30SD ULT30SD (V), ULT30SD(TM)
		C	-----	0.05	
		D	-----	0.1	
		E	2.5	2.48	
145-440-0 (145-974-0 for Roller)	ULT50	A	21	20.95	ULT40, ULT40D, ULT40D(V) ULT40D(T), ULT40(TM) ULT40D(TM), ULT40T2(TM) ULT40DT2(TM), ULT40S ULT40SD, ULT40S(TM) ULT40SD(TM), ULT50, ULT50D ULT50L, ULT50DL, ULT50D(V) ULT50DL(V), ULT50D(T) ULT50DL(T), ULT50(TM) ULT50D(TM), ULT50L(TM) ULT50DL(TM), ULT50T2(TM) ULT50DT2(TM), ULT50S ULT50SD, ULT50SL, ULT50SDL ULT50S(TM), ULT50SD(TM) ULT50SL(TM)ULT50SDL(TM) ULT50C, ULT50CL, ULT50C(TM) ULT50CL(TM), ULT51SDL ULT51SDL(TM)
		C	-----	0.05	
		D	-----	0.1	
		E	2.5	2.48	
145-440-6 (145-974-6 for Roller)	ULT60	A	26	25.95	ULT60, ULT60D, ULT60L ULT60DL, ULT60D(V) ULT60DL(V), ULT60D(T) ULT60DL(T), ULT60(TM) ULT60D(TM), ULT60L(TM) ULT60DL(TM), ULT60T2(TM) ULT60DT2(TM), ULT60S ULT60SD, ULT60SL, ULT60SDL ULT60S(TM), ULT60SD(TM) ULT60SL(TM), ULT60SDL(TM) ULT60C, ULT60CL, ULT60C(TM) ULT60CL(TM)
		C	-----	0.05	
		D	-----	0.1	
		E	2.5	2.48	



Repair Limits - ULT Series

REPAIR LIMITS		DRIVING BLADE (ULT)			2/2
					
<p>Note 1: Make sure that neither deformation nor damage is observed.</p> <p>Note 2: Make sure that no damage on contact surface is observed.</p>					
CODE NO.	MOTHER MODEL	STANDARD DIMENSION		REPAIR LIMIT	MODEL
147-440-6 (147-974-6 for Roller)	ULT70	A	28	27.95	ULT70, ULT70L, ULT70(TM) ULT70L(TM), ULT70T2(TM) ULT70S, ULT70SL, ULT70S(TM) ULT70SL(TM), ULT70C, ULT70CL ULT70C(TM), ULT70CL(TM) ULT70CH, ULT70CHL ULT70CH(TM), ULT70CHL(TM)
		C	-----	0.05	
		D	-----	0.1	
		E	2.5	2.48	
147-440-8 (147-974-8 for Roller)	ULT90	A	30	29.95	ULT90, ULT90L
		C	-----	0.05	
		D	-----	0.1	
		E	2.5	2.48	
148-440-2 (148-974-2 for Roller)	ULT100	A	35	34.95	ULT100, ULT100L
		C	-----	0.05	
		D	-----	0.1	
		E	3	2.98	
130-440-2 (130-974-2 for Roller)	ULT130	A	40	39.95	ULT130, ULT130L
		C	-----	0.05	
		D	-----	0.1	
		E	3	2.98	
130-440-4 (130-974-2 for Roller)	ULT150 (ULT130 for Roller)	A	40	39.95	ULT150, ULT150L
		C	-----	0.05	
		D	-----	0.1	
		E	3	2.98	
128-440-2 (128-974-2 for Roller)	ULT180	A	45	44.95	ULT180, ULT180L
		C	-----	0.05	
		D	-----	0.1	
		E	3	2.98	


Repair Limits - ULT Series

REPAIR LIMITS		REAR LINER PLATE (ULT)		1/2	
					
Note Make sure that any deformation is not observed.					
CODE NO.	MOTHER MODEL	STANDARD DIMENSION		REPAIR LIMIT	MODEL
144-901-0	ULT30D	A	10	10.02	ULT30D, ULT30D(V) ULT30D(TM), ULT30SD ULT30SD (V), ULT30SD(TM)
		B	-----	0.01	
145-901-0	ULT50	A	12	12.023	ULT40, ULT40D, ULT40D(V) ULT40D(T), ULT40(TM) ULT40D(TM), ULT40T2(TM) ULT40DT2(TM), ULT40S, ULT40SD ULT40S(TM), ULT40SD(TM), ULT50 ULT50D, ULT50L, ULT50DL ULT50D(V), ULT50DL(V) ULT50D(T), ULT50DL(T) ULT50(TM), ULT50D(TM) ULT50L(TM), ULT50DL(TM) ULT50T2(TM), ULT50DT2(TM) ULT50S, ULT50SD, ULT50SL ULT50SDL, ULT50S(TM) ULT50SD(TM), ULT50SL(TM) ULT50SDL(TM), ULT50C, ULT50CL ULT50C(TM), ULT50CL(TM) ULT51SDL, ULT51SDL(TM)
		B	-----	0.01	
145-901-6	ULT60	A	12	12.023	ULT60, ULT60D, ULT60L ULT60DL, ULT60D(V), ULT60DL(V) ULT60D(T), ULT60DL(T) ULT60(TM), ULT60D(TM) ULT60L(TM), ULT60DL(TM) ULT60T2(TM), ULT60DT2(TM) ULT60S, ULT60SD, ULT60SL ULT60SDL, ULT60S(TM) ULT60SD(TM), ULT60SL(TM) ULT60SDL(TM), ULT60C, ULT60CL ULT60C(TM), ULT60CL(TM)
		B	-----	0.01	
147-901-6	ULT70	A	12	12.023	ULT70, ULT70L, ULT70(TM) ULT70L(TM), ULT70T2(TM) ULT70S, ULT70SL, ULT70S(TM) ULT70SL(TM), ULT70C, ULT70CL ULT70C(TM), ULT70CL(TM) ULT70CH, ULT70CHL ULT70CH(TM), ULT70CHL(TM)
		B	-----	0.01	


Repair Limits - ULT Series

REPAIR LIMITS		LINER (ULT)		1/2	
<div style="display: flex; justify-content: space-around; align-items: center;">   </div> <p style="text-align: center;">Note: Make sure that neither deformation nor damage is observed.</p>					
CODE NO.	MOTHER MODEL	STANDARD DIMENSION		REPAIR LIMIT	MODEL
144-902-0	ULT30D	A	16	16.015	ULT30D, ULT30D(V)
		C	28.5	28.485	ULT30D(TM), ULT30SD
		D	21	20.99	ULT30SD (V), ULT30SD(TM)
145-902-0	ULT50	A	18	18.015	ULT40, ULT40D, ULT40D(V) ULT40D(T), ULT40(TM) ULT40D(TM), ULT40T2(TM) ULT40DT2(TM), ULT40S ULT40SD, ULT40S(TM) ULT40SD(TM), ULT50
		C	30	29.985	ULT50D, ULT50L, ULT50DL ULT50D(V), ULT50DL(V) ULT50D(T), ULT50DL(T) ULT50(TM), ULT50D(TM) ULT50L(TM), ULT50DL(TM) ULT50T2(TM), ULT50DT2(TM) ULT50S, ULT50SD, ULT50SL ULT50SDL, ULT50S(TM)
		D	21	20.99	ULT50SD(TM), ULT50SL(TM) ULT50SDL(TM), ULT50C ULT50CL, ULT50C(TM) ULT50CL(TM), ULT51SDL ULT51SDL(TM)
145-902-6	ULT60	A	18	18.015	ULT60, ULT60D, ULT60L ULT60DL, ULT60D(V) ULT60DL(V), ULT60D(T) ULT60DL(T), ULT60(TM)
		C	30	29.985	ULT60D(TM), ULT60L(TM) ULT60DL(TM), ULT60T2(TM) ULT60DT2(TM), ULT60S ULT60SD, ULT60SL, ULT60SDL
		D	26	25.99	ULT60S(TM), ULT60SD(TM) ULT60SL(TM), ULT60SDL(TM) ULT60C, ULT60CL, ULT60C(TM) ULT60CL(TM)

Repair Limits - ULT Series

REPAIR LIMITS		LINER (ULT)			2/2
					
<p>Note: Make sure that neither deformation nor damage is observed.</p>					
CODE NO.	MOTHER MODEL	STANDARD DIMENSION		REPAIR LIMIT	MODEL
147-902-6	ULT70	A	20	20.015	ULT70, ULT70L, ULT70(TM) ULT70L(TM), ULT70T2(TM) ULT70S, ULT70SL, ULT70S(TM) ULT70SL(TM), ULT70C ULT70CL, ULT70C(TM) ULT70CL(TM), ULT70CH ULT70CHL, ULT70CH(TM) ULT70CHL(TM)
		C	33	32.985	
		D	28	27.99	
147-902-8	ULT90	A	23	23.015	ULT90, ULT90L, ULT90(TM) ULT90L(TM), ULT90T2(TM)
		C	38	37.985	
		D	30	29.99	
148-902-2	ULT100	A	26	26.015	ULT100, ULT100L, ULT100(TM) ULT100L(TM), ULT100T2(TM)
		C	42	41.985	
		D	35	34.99	
130-902-2	ULT130	A	27	27.015	ULT130, ULT130L, ULT130(TM) ULT130L(TM), ULT130T2(TM)
		C	46	45.985	
		D	40	39.99	
130-902-4	ULT150	A	32	32.03	ULT150, ULT150L, ULT150(TM) ULT150L(TM)
		C	52	51.985	
		D	40	39.99	
128-902-2	ULT180	A	36	36.03	ULT180, ULT180L, ULT180(TM) ULT180L(TM)
		C	56	55.985	
		D	45	44.99	

Repair Limits - ULT Series

REPAIR LIMITS		FRONT LINER PLATE (ULT)		1/2	
					
<p>Note Make sure that any deformation is not observed.</p>					
CODE NO.	MOTHER MODEL	STANDARD DIMENSION		REPAIR LIMIT	MODEL
144-904-0	ULT30D	A	16	16.023	ULT30D, ULT30D(V) ULT30D(TM), ULT30SD ULT30SD (V), ULT30SD(TM)
		B	-----	0.01	
145-904-6	ULT60	A	16	16.023	ULT40, ULT40D, ULT40D(V) ULT40D(T), ULT40(TM) ULT40D(TM), ULT40T2(TM) ULT40DT2(TM), ULT40S, ULT40SD ULT40S(TM), ULT40SD(TM), ULT50 ULT50D, ULT50L, ULT50DL ULT50D(V), ULT50DL(V) ULT50D(T), ULT50DL(T) ULT50(TM), ULT50D(TM) ULT50L(TM), ULT50DL(TM) ULT50T2(TM), ULT50DT2(TM) ULT50S, ULT50SD, ULT50SL ULT50SDL, ULT50S(TM) ULT50SD(TM), ULT50SL(TM) ULT50SDL(TM), ULT50C, ULT50CL ULT50C(TM), ULT50CL(TM) ULT51SDL, ULT51SDL(TM) ULT60, ULT60D, ULT60L ULT60DL, ULT60D(V), ULT60DL(V) ULT60D(T), ULT60DL(T) ULT60(TM), ULT60D(TM) ULT60L(TM), ULT60DL(TM) ULT60T2(TM), ULT60DT2(TM) ULT60S, ULT60SD, ULT60SL ULT60SDL, ULT60S(TM) ULT60SD(TM), ULT60SL(TM) ULT60SDL(TM), ULT60C, ULT60CL ULT60C(TM), ULT60CL(TM)
		B	-----	0.01	
147-904-6	ULT70	A	16	16.023	ULT70, ULT70L, ULT70(TM) ULT70L(TM), ULT70T2(TM) ULT70S, ULT70SL, ULT70S(TM) ULT70SL(TM), ULT70C, ULT70CL ULT70C(TM), ULT70CL(TM)
		B	-----	0.01	ULT70CH, ULT70CHL ULT70CH(TM), ULT70CHL(TM)



Corporate Headquarters

10000 SE Pine Street
Portland, OR 97216
800-852-1368
FAX 800-582-9015
www.aimco-global.com

Ave. Cristóbal Colon 14529
Chihuahua, Chihuahua. 31125
Mexico
011-52-(614) 380-1010
FAX 011-52-(614) 380-1019